



700 LX Series Heated CLD NO_x Analyzer



- New Electronics
- User-Friendly Operation
- New, More Powerful Operating System
- Proven Analytical Components
- Remote Emulation/Control Software TCP/IP

Features

- Measures From 3 ppm up to 3,000 ppm Full Scale
- Three Measurement Modes—NO, NO_x and NO/NO₂/NO_x
- Heated Oven Allows Hot/Wet Sampling
- Auto Calibration and Ranging
- Fast Response Time
- Robust and Rugged Linux Based Operating System
- Electronic Sample and Ozone Flow Control
- Does Not Require Vacuum Pump
- Comprehensive Diagnostics
- Standard Outputs: Voltage, Current, AK Protocol, RS-232 AK Protocol, TCP/IP MODBUS
- CE Mark and ETL Listed—Conforms to UL STD 61010-1, Certified to CAN/CSA C22.2 STD No. 610610.1
- 1065 and ECE 49-06 Compliant

Applications

- Combustion Efficiency
- Fuel Cell Analysis
- Turbine/Generator Feedback Control
- Ammonia Slip
- Process Chemical Gas Analysis
- Personnel Safety
- Pharmaceutical Processes
- Vehicle Emissions

Options

- Internal Sample Pump
- Internal Calibration Solenoid Valves
- Internal Ozone Pump
- Low Flow
- Low Pressure
- 19 Inch Rack Mount Slides

California Analytical Instruments

1312 West Grove Avenue, Orange, CA 92865 • Phone: 714-974-5560 • Fax: 714-921-2531
www.gasanalyzers.com



700 LX Series Heated CLD NOx Analyzer

Method of Operation

The California Analytical 700 LX Series HCLD Analyzer utilizes the principle of chemiluminescence for analyzing the NO or NO_x concentration within a gaseous sample. In the NO mode, the method is based upon the chemiluminescent reaction between ozone and nitric oxide (NO) yielding nitrogen dioxide (NO₂) and oxygen. This reaction produces light which has intensity proportional to the mass flow rate of NO₂ into the reaction chamber.

The light is measured by means of a photodiode and associated amplification electronics. In the NO_x mode, NO plus NO₂ is determined as above, however, the sample is first routed through the Internal NO₂ to NO converter which converts the NO₂ in the sample to NO. The resultant reaction is directly proportional to the total concentration of NO_x.

Specifications

Detector: Photodiode
NO/NO_x Ranges: Four User-definable from 0-3 to 0-3,000 ppm NO/NO_x (Higher Ranges Available upon Request)
Response Time: Typically < 3 Seconds to 90% Full Scale
Repeatability: Better than 0.5% of Full Scale
Linearity: Better than 1% of Full Scale
Accuracy: Better than 1% Full Scale
Precision: Better than 0.5% Full Scale
Noise: Less than 0.5% of Full Scale
Zero & Span Drift: Less than 1% of Full Scale per 24 Hours
CO₂ Effect: Less than 2% with 10% CO₂
H₂O Effect: Less than 1% with 1% H₂O
Interference Data: CO, HCN, SO₂, NH₃, N₂O not Detectable at 100 ppm
Flow Control: Electronic Proportional Pressure Controller
Sample Flow Rate : Typically 1.5 to 2.5 LPM (0.6 LPM with Low Flow Option)
Converter: Carbon Material @ 205 C; 95 to 100% Efficiency
Ozonator: Ultraviolet Lamp
Air or O₂ Requirements: Dry Air less than 0.01 ppm NO_x at 350 cc/Min. @ 25 psig (Dew Point < -10°C

NO/NO_x Control: Manual/Remote/Auto Cycle
Standard Outputs: Voltage, Current, RS-232 AK Protocol, TCP/IP MODBUS and AK Protocol
Assignable Contact Alarms and Statuses: 15 Assignable Contact Closures
Digital Diagnostics: Temperature, Pressure, EPC Volt %, and Flow
Display: 3" x 5" LED LCD
Sample Temperature: 85-100°C
Oven Temperature: 85°C Standard, 100°C Upon Request
Ambient Temperature: 5 to 40°C
Ambient Humidity: Less than 90% RH (Non-condensing)
Warm Up Time: 1 Hour
Fittings: 1/4 Inch Tube
Power Requirements: 115/230 VAC; 50/60 Hz; 560 Watts
Dimensions: 5¼ H x 19 W x 23 D (Inches)
Weight: 45 Pounds

Specifications subject to change without notice.

California Analytical Instruments

1312 West Grove Avenue, Orange, CA 92865 • Phone: 714-974-5560 • Fax: 714-921-2531
www.gasanalyzers.com